

Visual3D Server To Visual3D


Connecting Visual3D Server to Visual3D.


VISUAL3D SERVER HAS BEEN REPLACED BY THE **VISUAL3D PLUGINS**

The first step to streaming data to the Visual3D Server is to set up the stream from the Motion Capture system:


Setting up Qualisys QTM



Streaming from the Visual3D Server to a Client





Streaming into Visual3D





From:
<https://has-motion.com/wiki/> - **Wiki Documentation Site**

Permanent link:
https://has-motion.com/wiki/doku.php?id=other:visual3dserver:visual3d_server_to_visual3d

Last update: **2024/07/17 15:44**

