If GENERATE_MEAN_AND_STDDEV=TRUE the mean and standard deviation are computed across all active files.

GENERATE MEAN AND STDDEV

From:
https://has-motion.com/wiki/ - **Wiki Documentation Site**

Permanent link:
https://has-motion.com/wiki/doku.php?id=visual3d:documentation:pipeline:signal_commands:generate_mean_and_stddev&rev=1721229815

Last update: **2024/07/17 15:23**