



Histogram of Image



The histogram of the image shows the range of voxel intensities in the currently loaded image data. If a label is selected in the *Segmentation* widget, the upper and lower thresholds of the label are represented in the histogram as red and green vertical lines, respectively. You can left-click and drag these lines to change the respective threshold values. Note: the label thresholds cannot be changed while the contrast function is displayed.



To change the contrast of the images in the 2D and 3D windows, check the *show contrast function* box to display the piece-wise linear function that controls the contrast. Left-click on a control point and drag it to change the contrast for the voxel intensities in that area. If you left-click away from a control point, a new control point will be added where you clicked. To remove a control point, middle-click on it.

From:
<https://has-motion.com/wiki/> - Wiki Documentation Site

Permanent link:
https://has-motion.com/wiki/doku.php?id=other:dsx:surface3d:histogram_of_image&rev=1721231059

Last update: 2024/07/17 15:44

