

Conditional_Entropy

The cross-conditional entropy, H , of the DRR image relative to the X-ray image is calculated and minimized by the optimization algorithm ^[1].



Parameters



Parameters for Conditional Entropy Metric

* **View Weighting** This factor is used when evaluating a bone pose by comparing the DRR images to the X-ray images. It is the relative weight of the two views in the final image metric (0.0 = all view 1, 1.0 = all view 2). 0.5 means to weight each view equally.

* **Constant DRR Scaling** Whether or not to scale the DRRs for each view by a constant value for all iterations of an optimization. If false, each DRR will be scaled so that its maximum value is equal to the DRR image scale value ([//X-ray/DRR Settings//](#) widget). If true, a single scale value will be calculated during the first iteration and be used to scale the DRRs in all subsequent iterations.

1. ↑ Wang F, Vemuri B, Rao M, Chen Y (2003). Cumulative residual entropy, a new measure of information & its application to image alignment. Proceedings of the Ninth IEEE International Conference on Computer Vision, October, 2003. DOI: 10.1109/ICCV.2003.1238395.

From:
<https://has-motion.com/wiki/> - Wiki Documentation Site

Permanent link:
https://has-motion.com/wiki/doku.php?id=other:dsx:x4d:conditional_entropy&rev=1721157692

Last update: 2024/07/16 19:21

