

E3D Export Setting File

The .e3d file format is a method of storing Inspect3D export settings as XML, ensuring that they are both human- and machine-readable. Inspect3D allows users to save export settings from the



Export Results dialog. Previously-saved export settings can also be loaded and used from this dialog.

Format

As an XML document, an .e3d file is made up of hierarchical elements that are demarcated by tags, indicated by the < and > characters. An element consists of a start tag, <elementname>, and end tag, </elementname>, and all of the characters in between. Alternatively, an element can be defined by a single tag, <elementname />.

Tags can also contain attributes in the *name*=*"value"* format, further describing the associated element.

1. The top-level element in an .e3d file is *exportFiles*. It contains one *folderpath* element, one or more *exportFile* elements, and one *I3D_Info* element.
2. The *folderPath* element has a single attribute, *path* which is the path to the folder to which all of the exported files will be saved.
3. The *exportFile* elements each describe a single exported file. These have a single attribute, *name*, which is the name of exported file. These also contain two elements: *exportData* and *settings*.
4. The *exportData* element records the position of the active plot, whether all groups and workspaces were selected, and provides a list of selected groups and a list of selected workspaces. This element is not read in when applying export settings again, but it provides a potentially useful record of the original export.
5. The *settings* element records the specific settings from the Export Results dialog. Only those settings from the active Export_Type will be included.
6. The *I3D_Info* element has a single attribute, *version* which is the version of Inspect3D used to create the .e3d file. This can be used for troubleshooting if the format of an .e3d file changes in the future.

DTD

Formally, an .e3d file respects the Document Type Definition (DTD):

```
<!DOCTYPE exportFiles [  
  <!ELEMENT exportFiles (folderpath,exportFile+,I3D_Info)>  
  <!ELEMENT folderpath ()>  
  <!ATTLIST folderpath path CDATA #REQUIRED>  
  <!ELEMENT exportFile (exportData,settings)>  
  <!ELEMENT exportData ()>  
  <!ATTLIST exportData col CDATA #REQUIRED  
    exportData row CDATA #REQUIRED  
    exportData SelAllGrp CDATA #REQUIRED  
    exportData SelAllWrkspc CDATA #REQUIRED  
    exportData SelGrps CDATA #REQUIRED  
    exportData SelWrspcs CDATA #REQUIRED  
  >  
  <!ELEMENT settings ()>  
  <!ATTLIST settings Export_Type CDATA #REQUIRED  
    settings Export_Data CDATA #REQUIRED  
    settings Group_Mean CDATA #IMPLIED  
    settings Group_StdDev CDATA #IMPLIED  
    settings Wrksp_Mean CDATA #IMPLIED  
    settings Wrkspc_StdDev CDATA #IMPLIED  
    settings Normalized_Sequences CDATA #IMPLIED  
    settings TimeBased_Sequences CDATA #IMPLIED  
    settings Normalized_Events CDATA #IMPLIED  
    settings Original_Events CDATA #IMPLIED  
    settings Normalized_Points CDATA #IMPLIED  
    settings Wrkspc_Scores CDATA #IMPLIED  
    settings Group_Scores CDATA #IMPLIED  
    settings Group_Scores_StdDev CDATA #IMPLIED  
    settings Variance_Explained CDATA #IMPLIED  
    settings Eigenvectors CDATA #IMPLIED  
    settings Mean_1SD CDATA #IMPLIED  
    settings Mean_5_and_95 CDATA #IMPLIED  
    settings Calculate_metrics_for CDATA #IMPLIED  
    settings Mean CDATA #IMPLIED  
    settings StdDev CDATA #IMPLIED  
    settings Min CDATA #IMPLIED  
    settings Min_StdDev CDATA #IMPLIED  
    settings Min_Event CDATA #IMPLIED  
    settings Max CDATA #IMPLIED  
    settings Max_StdDev CDATA #IMPLIED  
    settings Max_Event CDATA #IMPLIED  
    settings Add_Metrics_Column CDATA #IMPLIED  
    settings Use_Normalized_Data CDATA #IMPLIED  
    settings Precision CDATA #REQUIRED  
    settings Export_Format CDATA #REQUIRED  
  >  
  <!ELEMENT I3D_Info ()>  
  <!ATTLIST I3D_Info version CDATA #REQUIRED>  

```

From:
<https://has-motion.com/wiki/> - **Wiki Documentation Site**

Permanent link:
https://has-motion.com/wiki/doku.php?id=other:inspect3d:documentation:files:e3d_export_setting_file&rev=1721231070

Last update: **2024/07/17 15:44**

