

Endian_Parameters

Visual3D will allow the file to be exported with any of the 3 Endians (byte ordering of integers and reals) regardless of the input Endian.

Acceptable Input Parameters:

1 = PC 2 = VAX 3 = SGI

From:
<https://has-motion.com/wiki/> - Wiki Documentation Site

Permanent link:
https://has-motion.com/wiki/doku.php?id=visual3d:documentation:definitions:endian_parameters&rev=1721157903

Last update: **2024/07/16 19:25**

