

Import_Analog_Noraxon_EMG_Signals

This command is deprecated. Instead export EMG signals from Noraxon directly to a C3D file and then import signals using the [Import_Signals_From_C3D_File](#) command.

Imports data from [Noraxon EMG](#) files into an existing [C3D](#) file.

```
Import_Analog_Noraxon_EMG_Signals  
/FILE_NAMES=  
/ANALOG_RATE=  
;
```

[Back to Pipeline Commands Reference](#)

From:
<https://has-motion.com/wiki/> - **Wiki Documentation Site**

Permanent link:
https://has-motion.com/wiki/doku.php?id=visual3d:documentation:emg:import_analog_noraxon_emg_signals&rev=1719433319

Last update: **2024/06/26 20:21**

