

Setup_RRA.xml

(modified from subject01_Setup_RRA.xml)

- The <CMCTool> name has been changed to Visual3d_walk1_RRA
- The <model_file> name has been changed to Visual3d_simbody.osim.
- The <initial_time> and <final_time> for RRA have been set to 0.0 and 1.0 but this will be changed by the user when operating OpenSim to match the desired time range for RRA
- The <desired_kinematics_file> is now Visual3d_SIMM_input.mot. This is the name of the file that is written by Visual3d containing the kinematics.
- The <external_loads_file> is now Visual3d_SIMM_input.mot. This is the name of the file that is written by Visual3d containing the fore platform information.
- The <external_loads_model_kinematics_file> is now Visual3d_SIMM_input.mot. This is the name of the file that is written by Visual3d containing the fore platform information.

From:
<https://has-motion.com/wiki/> - **Wiki Documentation Site**

Permanent link:
https://has-motion.com/wiki/doku.php?id=visual3d:documentation:opensim:setup_rra.xml&rev=1721158062

Last update: **2024/07/16 19:27**

