Joint Rotations From PSU IMU

This command is not available for common use.

Creates LinkModelBased joint rotations based on PSU IMU data.
Target 1 = origin
Target 2 = origin - (0,0,marker_distance)
Target 3 = origin + (0,marker_distance,0)

```
Joint_Rotations_From_PSU_IMU
/MOTION_FILE=
/FLOOR_FILE=
/SUBJECT_CAL_FILE=
/C3D_FILE=
;
```

Back to Pipeline Commands Reference

From:
https://has-motion.com/wiki/ - **Wiki Documentation Site**

Permanent link:
https://has-motion.com/wiki/doku.php?id=visual3d:documentation:pipeline:file_commands:joint_rotations_from_psu_imu

Last update: **2024/07/17 15:45**