

Joint_Rotations_From_PSU_IMU

This command is not available for common use.

Creates LinkModelBased joint rotations based on PSU IMU data.

Target 1 = origin

Target 2 = origin - (0,0,marker_distance)

Target 3 = origin + (0,marker_distance,0)

```
Joint_Rotations_From_PSU_IMU
/MOTION_FILE=
/FLOOR_FILE=
/SUBJECT_CAL_FILE=
/C3D_FILE=
;
```

[Back to Pipeline Commands Reference](#)

From:

<https://has-motion.com/wiki/> - Wiki Documentation Site

Permanent link:

https://has-motion.com/wiki/doku.php?id=visual3d:documentation:pipeline:file_commands:joint_rotations_from_psu_imu&rev=1720790979

Last update: 2024/07/12 13:29

