

# Remove\_Segment\_Assignment\_To\_Force\_And\_COP

The Remove\_Segment\_Assignment\_To\_Force\_And\_COP command allows users to programmatically update force assignments via a pipeline script.

## Pipeline Command

The Remove\_Segment\_Assignment\_To\_Force\_And\_COP is found in the pipeline workshop's Force folder.

```
Remove_Segment_Assignment_To_Force_And_COP
! /FORCE_SIGNAL_TYPE=
! /FORCE_SIGNAL_FOLDER=
/FORCE_SIGNAL_NAME=
! /COP_SIGNAL_TYPE=
! /COP_SIGNAL_FOLDER=
/COP_SIGNAL_NAME=
! /FREEMOMENT_SIGNAL_TYPE=
! /FREEMOMENT_SIGNAL_FOLDER=
! /FREEMOMENT_SIGNAL_NAME=
! /SEGMENT_NAME=
! /START_FRAME=
! /END_FRAME=
! /INSIDE_FRAME=
! /EVENT_SEQUENCE=
! /EXCLUDE_EVENTS=
;
```

## Command Parameters

| Parameter                 | Description |
|---------------------------|-------------|
| Force Signal Type         |             |
| Force Signal Folder       |             |
| Force Signal Name         |             |
| COP Signal Type           |             |
| COP Signal Folder         |             |
| COP Signal Name           |             |
| Free Moment Signal Type   |             |
| Free Moment Signal Folder |             |
| Free Moment Signal Name   |             |
| Segment Name              |             |
| Start Frame               |             |

| Parameter      | Description |
|----------------|-------------|
| End Frame      |             |
| Inside Frame   |             |
| Event Sequence |             |
| Exclude Events |             |

## Example

TBC

From:  
<https://has-motion.com/wiki/> - Wiki Documentation Site

Permanent link:  
[https://has-motion.com/wiki/doku.php?id=visual3d:documentation:pipeline:force\\_commands:remove\\_segment\\_assignment\\_to\\_force\\_and\\_cop](https://has-motion.com/wiki/doku.php?id=visual3d:documentation:pipeline:force_commands:remove_segment_assignment_to_force_and_cop)

Last update: 2026/09/09 20:49

