

Export Metric Table To ODT

Merge metrics to a table of an ODT document.

Dialog

Exported Ascii File

Browse

Row	Co...	Legend	Owner	Type	Folder	Name	Co...
-----	-------	--------	-------	------	--------	------	-------

Table Name

Cell Properties

Signal Owner

Signal Type

Signal Folder

Signal Name

Components (X,Y,Z,R or 1,2,3,..)

Row

Column

Legend Text

Add a New Signal

Modify Selected

Delete Selected

OK

Cancel

```
Export_Metric_Table_To_ODT
! /FILE_NAME=
/TABLE_NAME=
! /OWNERS=
/SIGNAL_TYPES=
! /SIGNAL_FOLDER=ORIGINAL
! /SIGNAL_NAMES=
! /SIGNAL_COMPONENTS=
! /ROW=
! /COLUMN=
;
```

From:
<http://has-motion.com/wiki/> - **Wiki Documentation Site**

Permanent link:
http://has-motion.com/wiki/doku.php?id=visual3d:documentation:pipeline:report_commands:export_metric_table_to_odt

Last update: **2024/07/17 15:46**

