

Merge metrics to a table of an ODT document.



```
Export_Metric_Table_To_ODT
! /FILE_NAME=
/TABLE_NAME=
! /OWNERS=
/SIGNAL_TYPES=
! /SIGNAL_FOLDER=ORIGINAL
! /SIGNAL_NAMES=
! /SIGNAL_COMPONENTS=
! /ROW=
! /COLUMN=
;
```

From:
<https://has-motion.com/wiki/> - Wiki Documentation Site

Permanent link:
https://has-motion.com/wiki/doku.php?id=visual3d:documentation:pipeline:report_commands:export_metric_table_to_odt&rev=1718805784

Last update: 2024/06/19 14:03

