

Export Metric Table To ODT

Merge metrics to a table of an ODT document.

Dialog

Exported Ascii File

Browse

Row	Co...	Legend	Owner	Type	Folder	Name	Co...

Table Name

Cell Properties

Signal Owner

Signal Type

Signal Folder

Signal Name

Components (X,Y,Z,R or 1,2,3,..)

Row

Column

Legend Text

Add a New Signal

Modify Selected

Delete Selected

OK

Cancel

```
Export_Metric_Table_To_ODT
! /FILE_NAME=
/TABLE_NAME=
! /OWNERS=
/SIGNAL_TYPES=
! /SIGNAL_FOLDER=ORIGINAL
! /SIGNAL_NAMES=
! /SIGNAL_COMPONENTS=
! /ROW=
! /COLUMN=
;
```

From:
<https://has-motion.com/wiki/> - **Wiki Documentation Site**

Permanent link:
https://has-motion.com/wiki/doku.php?id=visual3d:documentation:pipeline:report_commands:export_metric_table_to_odt&rev=1721229810

Last update: **2024/07/17 15:23**

